



Instruction to FastChecker Software Download and Installation

Go to www.getfasttag.com


Click in Software




Type your name and your email and press "Baixar"



The software in a ZIP file will be saved in your computer. Unzip it and run FastCheckerInstaller_1.4.4.exe






Choose “I agree” to have it installed in your computer

After the installation is completed a FastChecker Icon will appear in your desktop.


Connect the FastChecker device into the USB Port. Make sure the FastChecker is recognized (install the drivers).




Double click in the FastChecker Icon

Follow the instruction 1 or 2 depending if you have the Authorization Token or if you have the license already issued.

1) If you have received the “Authorization Token”
Go to License , then go to Auto License and type the “Authorization Token” for your unit. We will deliver to you the “Authorization Token”



After this you will see that the license is OK .



2) If you have the already the license

Go to License , then go to Import License.

Point to the Licence file and click OK.

After this you will see that the license is OK .

FastChecker - Microsoft Edge
127.0.0.1/pages/license.xhtml

Projects Antenna Check Noise Check License FAQ / Help Press F11 to fullScreen

System Information

Software: 1.4.3 Hardware: 7.0.4 Firmware: 1.1.4
Device licensed

Reload system information

License Information

Auto License Import .lic

Serial Number: FC01-EVT License Issue Date: 10/12/2019 19:22:00

License Type: FastChecker Frequency Range: [800 - 1000] MHz Power Range: 5 - 25 dBm

Export .lic Delete

Type here to search 11:55 10/01/2020